


Развилка

- A7 B7 C7 D7 E7 F7 G7 H7 I7 J7
- A8 B8 C8 D8 E8 F8 G8 H8 I8 J8
- A9 B9 C9 D9 E9 F9 G9 H9 I9 J9
- A10 B10 C10 D10 E10 F10 G10 H10 I10 J10
- A11 B11 C11 D11 E11 F11 G11 H11 I11 J11
- A12 B12 C12 D12 E12 F12 G12 H12 I12 J12
- A13 B13 C13 D13 E13 F13 G13 H13 I13 J13
- A14 B14 C14 D14 E14 F14 G14 H14 I14 J14
- A15 B15 C15 D15 E15 F15 G15 H15 I15 J15



K7

L7

M7

N7

O7

P7

Q7

R7

S7

T7

U7

V7

W7

K8

L8

M8

N8

O8

P8

Q8

R8

S8

T8

U8

V8

W8

K9

L9

M9

N9

O9

P9

Q9

R9

S9

T9

U9

V9

W9

K10

L10

M10

N10

O10

P10

Q10

R10

S10

T10

U10

V10

W10

K11

L11

M11

N11

O11

P11

Q11

R11

S11

T11

U11

V11

W11

K12

L12

M12

N12

O12

P12

Q12

R12

S12

T12

U12

V12

W12

K13

L13

M13

N13

O13

P13

Q13

R13

S13

T13

U13

V13

W13

K14

L14

M14

N14

O14

P14

Q14

R14

S14

T14

U14

V14

W14

K15

L15

M15

N15

O15

P15

Q15

R15

S15

T15

U15


V15


W15


Куст 304

Куст 310


северо-поточная














8825500  
8825000  
8824500  
8824000  
8823500  
8823000  
8822500  
8822000  
8821500  
8821000  
8820500  
8820000  
8819500  
8819000  
8818500

A26 B26 C26 D26 E26 F26 G26 H26 I26 J26  
A27 B27 C27 D27 E27 F27 G27 H27 I27 J27  
A28 B28 C28 D28 E28 F28 G28 H28 I28 J28  
A29 B29 C29 D29 E29 F29 G29 H29 I29 J29  
A30 B30 C30 D30 E30 F30 G30 H30 I30 J30

Куст 2


Куст 70

Куст 58B

Куст 60

Озеро По

528500 529000 529500 530000 530500 531000 531500 532000 532500 533000 533500 534000 534500 535000



Куст 329


Опора № 108

Куст 327

Куст 326

ТОЧНОЕ

535500 536000 536500 537000 537500 538000 538500 539000 539500 540000 540500 541000 541500



8823000  
8822500  
8822000  
8821500  
8821000  
8820500  
8820000  
8819500  
8819000  
8818500

542500 543000 543500 544000 544500 545000 545500 546000 546500 547000 547500 8818500